

Valid for the following inverter models

- VFB40-004 to VFB40-046
- VFX40-018 to VFX40-750
- VFX50-018 to VFX50-750
- Software VFB/VFX V2.xx
- Software CRIO RN022100.1xx

CRANE OPTION for VFB/VFX (CRIO and Crane Interface)

INSTRUCTION MANUAL

English

Document number: 800840 02

Edition: R3

Date of release: 28-2-2002

© Copyright Emotron B.V. 2002

Emotron retain the right to change specifications and illustrations in the text, without prior notice. The contents of the document may not be copied without written permission from Emotron B.V.

Instruction manual

Read this instruction manual first!
Read also the VFB/VFX instruction manual first.

Software version

Check always that the software version number on the title page of this instruction manual is the same as used on the CRIO Card.

Safety instructions

Read the safety instructions in the VFB/VFX manual!

Technically qualified personnel

Installation, commissioning, demounting, making measurements, etc. of or on the frequency inverter may only be carried out by personnel who are technically qualified for the task.

Installation

Installation must be made by authorised personnel only and according to the local standards. Ensure that all necessary safety measures are taken.



DANGER! Take all necessary safety precautions during installation and commissioning to prevent personal injuries, e.g. by an uncontrolled load.

Opening the frequency inverter



DANGER! Always switch off the mains supply before opening the inverter and wait at least 5 minutes to allow the buffer capacitors to discharge.

Always take adequate precautions before opening the frequency inverter, although the connections for the control signals and jumpers are isolated from the mains voltage.

Motor ID-run

For optimum performance of the VFB/VFX inverter it is recommended to perform a Motor ID-run (window 228). For cranes only a Short ID-run without rotating the motor should be performed.



DANGER! PERFORM A SHORT ID-RUN ONLY WITHOUT ROTATING THE MOTOR TO PREVENT UNCONTROLLED BEHAVIOUR BY THE LOAD, E.G. DROPPING.

Disconnecting the CRIO card:



WARNING! ALWAYS DEACTIVATE THE CRIO CARD IN WINDOW 281 BEFORE DISCONNECTING IT.

Hoisting drives:



WARNING! Make sure the encoder function (window 251) and the deviation function (jumper j 101) are activated. The function „motor lost“ (window 353) must be set to „trip“. Check these functions carefully. They are safety related and prevent the load from falling down.

TABLE OF CONTENTS

1. GENERAL INFORMATION	5	5.3	Mechanical brake	15
1.1 Option package contents	5	5.3.1	Mechanical brake function at start	15
1.1.1 CRIO Card	5	5.3.2	Mechanical brake function at stop	16
1.1.2 Crane Interface.....	5	5.3.3	Cooperation of brake and deviation function.....	16
1.2 Introduction.....	5	5.3.4	Recommendation for tbh	17
1.3 Notes, cautions, warnings and danger signs.....	5	5.4	Magnetizing the motor.....	17
1.4 Description.....	5	5.5	(Pre)limit switches	17
1.4.1 For whom is this instruction manual intended?.....	5	5.5.1	Operation of limit switch without activated prelimit switch.....	17
1.5 Standards.....	5	5.6	Fast reverse	17
2. CRIO HARDWARE	6	5.7	Scaling	17
2.1 CRIO Printed Circuit Board layout and dimensions.....	6	5.8	CRIO Relay CR1	18
2.1.1 Jumper	6	5.9	Load dependent field weakening operation.....	18
2.2 Mounting of the CRIO Card	6	5.10	Encoder.....	19
2.2.1 In the VFX	6	5.11	PTC.....	19
2.2.2 Outside the VFB	6	6. VFB/VFX MENU	20	
2.3 CRIO connections.....	7	6.1	Additional functions for CRIO in Window 280.....	20
2.3.1 X1: CRIO Relay CR1 & 2.....	7	6.1.1	281 CRIO Card	20
2.3.2 X2: PTC.....	7	6.1.2	282 Control	20
2.3.3 X5: CRIO User Interface.....	7	6.1.3	283 CRIO Relay CR2	20
2.3.4 X6: For Sub-d connectors to Crane Interface	7	6.1.4	284 Deviation Time.....	20
2.3.5 X7: Encoder.....	8	6.1.5	285 Set Load.....	20
3. CRANE INTERFACE	9	6.2	Added PTC function for CRIO in Window 270.....	21
3.1 Crane Interface.....	9	6.2.1	271 PTC (Card)	21
3.2 Mounting the Crane Interface.....	9	6.3	Added Encoder functions for CRIO in Window 250	21
3.3 Crane Interface layout	10	6.3.1	251 Encoder (Card)	21
3.4 Crane Interface connections	10	6.3.2	252 Encoder pulses	21
4. SETUP CRIO AND VFB/VFX	11	7. 4-SPEED CONTROLLER OPERATION	23	
4.1 Connecting CRIO and Crane Interface.....	11	7.1	Windows for setting the speeds for 4-Speed controller operation	23
4.1.1 CRIO inside VFX	11	7.2	Windows for setting the brake functions.	23
4.1.2 CRIO outside VFB	11	7.3	Connection example for 4-Speed controller operation.....	23
4.1.3 Crane Interface (with CRIO inside VFX) ..	11	8. 3-POS SWITCH OPERATION.....	25	
4.1.4 Crane Interface (with CRIO outside VFB) ..	11	8.1	Windows for setting the speeds for 3-Position switch operation.....	25
4.2 External circuitry	11	8.2	Windows for setting the brake functions.	25
4.2.1 With 4-Speed control	11	8.3	Connection example for 3-Position switch operation.....	25
4.2.2 With 3-Position control	11	9. ANALOGUE CONTROL	27	
4.2.3 With analogue control.....	11	9.1	Windows for setting up analogue control operation.....	27
4.2.4 PTC and Encoder	11	9.2	Windows for setting the brake functions.	27
4.2.5 Brake.....	11	9.3	Window for AnIn1 Setup	27
4.2.6 Functionality of VFB/VFX User Interface when CRIO Card connected.....	11	9.4	Connection example for 4-20mA analogue control operation	27
4.3 Programming the VFB/VFX	11	10. SETUP MENU LIST	29	
4.3.1 Unhidden windows when CRIO Card connected and their defaults.....	11	11. INDEX.....	34	
4.3.2 Changed defaults when CRIO Card activated.....	12	REPRESENTATIVES.....	36	
4.3.3 Programming general	12			
4.3.4 Disconnecting the CRIO Card	12			
4.3.5 Programming VFB/VFX for riding applications.....	13			
4.3.6 Programming VFB/VFX for hoisting applications.....	13			
5. FUNCTIONS	14			
5.1 Control.....	14			
5.1.1 4-Speed controller	14			
5.1.2 3-Position switch	14			
5.1.3 Analogue control	14			
5.2 Deviation.....	14			
5.2.1 Deviation function.....	14			
5.2.2 (De)activating deviation function.....	15			

LIST OF FIGURES

Fig. 1:	CRIO PCB layout and dimensions.	6
Fig. 2:	Mounting the CRIO inside the inverter (possible for VFX).	6
Fig. 3:	Mounting the CRIO outside the inverter (necessary for VFB).	7
Fig. 4:	Mounting the Crane Interface when the CRIO is mounted inside the inverter (possible for VFX).	9
Fig. 5:	Mounting the Crane Interface when the CRIO is mounted outside the inverter (necessary for VFB).	9
Fig. 6:	Crane Interface layout.	10
Fig. 7:	4-Speed controller.	14
Fig. 8:	3-Position switch.	14
Fig. 9:	Analogue control.	14
Fig. 10:	Diagram for brake function at start of hoisting.	15
Fig. 11:	Diagram for brake function at start of lowering.	15
Fig. 12:	Diagram for brake function at stop hoisting.	16
Fig. 13:	Diagram for brake function at stop lowering.	16
Fig. 14:	Recommended brake circuitry.	16
Fig. 15:	Effect of (pre)limit switches.	17
Fig. 16:	Effect of scaling the speed reference from the CRIO Card.	18
Fig. 17:	CRIO Relay CR1 function.	18
Fig. 18:	Theoretical load dependent field weakening operation.	18
Fig. 19:	Settings for load dependent field weakening operation.	18
Fig. 20:	Encoder inputs A-A'/B-B' switching level.	19
Fig. 21:	General diagram for 4-Speed controller operation.	23
Fig. 22:	Connection diagram for 4-Speed controller operation.	23
Fig. 23:	General diagram for 3-position switch operation.	25
Fig. 24:	Connection diagram for 3-Position switch operation.	25
Fig. 25:	General diagram for analogue control operation.	27
Fig. 26:	Connection diagram for 4-20mA analogue control operation.	27

1. GENERAL INFORMATION

1.1 Option package contents

1.1.1 CRIO Card

For internal mounting the CRIO Card option contains:

- CRIO Card
- Flat cable CB (X5) – CRIO (X3)
- Mounting material
- This manual

For external mounting the CRIO Card option contains extra:

- Housing (Phoenix) for DIN-rail mounting:
 - 1x Profile housing UM108-profile 21.1cm
 - 1x Side element UM108-SEFE/R
 - 1x Side element UM108-SEFE/L
 - 1x Base element UM108-FE
 - 1x Perspex cover
- Cable from CB (X5) – CRIO (X3) through gland.
- Mounting material

1.1.2 Crane Interface

The Crane Interface extension contains:

- Crane Interface (suitable for DIN-rail mounting).
- Cable 20p header – 2x Sub-d

When the CRIO card is mounted inside the inverter, the Crane Interface extension contains:

- Crane Interface (suitable for DIN-rail mounting).
- Cable 20p header – 2x Sub-d (bottom of inverter).
- 2x Cable Sub-d – Sub-d

1.2 Introduction

The CRIO Card is an option for the VFB/VFX frequency inverters, which offers the inputs and outputs necessary for operating cranes. It can be extended with a Crane Interface option that provides mains isolated I/O when long control leads are used or to solve EMC problems.

Read this instruction manual carefully before commencing installation, connecting or working with the frequency inverter with CRIO Card (and Crane Interface).

1.3 Notes, cautions, warnings and danger signs

The following indications have the meanings given and are printed in bold typeface:

NOTE! Additional information as an aid to avoid problems.

CAUTION!




Failure to follow these instructions can result in malfunction or damage to the frequency inverter.

WARNING!



Failure to follow these instructions can result in serious injury to the user in addition to serious damage to the frequency inverter.

DANGER!



The life of the user is in danger.

1.4 Description

This instruction manual describes the installation and use of the option CRIO Card and Crane Interface in combination with the frequency inverters of the following type:

- VFB40-004 to VFB40-046
- VFX40-018 to VFX40-750
- VFX50-018 to VFX50-750

1.4.1 For whom is this instruction manual intended?

This instruction manual is intended for:

- Installation engineers
- Maintenance personnel
- Operators
- Designers
- Service engineers

1.5 Standards

See the VFB/VFX Instruction manual.

2. CRIO HARDWARE

2.1 CRIO Printed Circuit Board layout and dimensions

Fig. 1 shows the CRIO PCB layout and dimensions.




Fig. 1: CRIO PCB layout and dimensions.

The LED's on the CRIO PCB have the following indication function:

LED	Indication
H101-1	Blinking = Communication with Control Board Steady On or Off = Communication Error
H101-2	On = Encoder rotation LEFT Off = Encoder rotation RIGHT
H101-3	On = Encoder signal slightly unstable
H101-4	On = Encoder signal error
H201	On = CR1 on
H202	On = CR2 on

2.1.1 Jumper

Jumper J101 activates the deviation function; see also § 5.2.2, page 15.

2.2 Mounting of the CRIO Card

2.2.1 In the VFX

The CRIO Card with detached snap-off strips is mounted inside the inverter, see Fig. 2, page 6.

Connect the supplied flat cable between CRIO connector X3 and Control Board connector X5. See also Fig. 4, page 9.




Fig. 2: Mounting the CRIO inside the inverter (possible for VFX).

2.2.2 Outside the VFB

The CRIO Card with attached snap-off strips is mounted outside the inverter with the supplied Phoenix Contact elements, suitable for DIN-rail mounting:

- 1x Profile housing UM108-profile 21.1cm
- 1x Side element UM108-SEFE/R
- 1x Side element UM108-SEFE/L
- 1x Base element UM108-FE
- Perspex cover

Connect the supplied cables between Control Board connector X5 and bottom of inverter and from there to CRIO connector X3. See also Fig. 3, page 7.




Fig. 3: Mounting the CRIO outside the inverter (necessary for VFB).

Max. inp. voltage: 30VDC
 Switching levels: HIGH >2.1V min
 LOW <0.5V max
 Input current: 1mA typ @5VDC
 2.5mA typ @10VDC
 7mA typ @24VDC

Pin	Name	Function
1	A1	Crawl Right/Hoist
2	B1	Preset Speed 2
3	E1	Limit Switch Right/Hoist
4	V2	Pre-limit Switch Left/Lower
5	E2	Limit switch Left/Lower
6	V1	Pre-limit Switch Right/Hoist
7	A2	Crawl Left/Lower
8	N	Null position
9	B2	Preset Speed 3
10	B3	Preset Speed 4
11	R1	2 nd Acc/Dec Time via Parameter Set B
12	R2	Inverter activated (Low=Inverter deactivated)
13	Gnd	Signal ground

2.3 CRIO connections

2.3.1 X1: CRIO Relay CR1 & 2

Specification: 1A/250VAC/AC1

Pin	Name	Function
1	CR1 P	CRIO Relay CR1: Central contact
2	CR1 NC	CRIO Relay CR1: Normally closed contact; opens when CR1 is activated.
3	CR1 NO	CRIO Relay CR1: Normally open contact; closes when CR1 is activated.
4	CR2 P	CRIO Relay CR2: Central contact
5	CR2 NC	CRIO Relay CR2: Normally closed contact; opens when CR2 is activated.
6	CR2 NO	CRIO Relay CR2: Normally open contact; closes when CR2 is activated.

2.3.2 X2: PTC

Specification: See §5.11, page 19.

Pin	Name	Function
1	PTC Pos	Motor thermistor pos connection
2	PTC Neg	Motor thermistor neg connection

2.3.3 X5: CRIO User Interface


Specification:

All inputs are active high up to 24V. Switching voltages at TTL level.

Voltage range: 5 – 24VDC typ

NOTE! The inputs E1, E2, V1, V2, R2 and NULL must be connected to +24VDC (or 230V for Crane Interface) when not used.

2.3.4 X6: For Sub-d connectors to Crane Interface

All X5 inputs are doubled, marked , into X6 and some I/O is added.

NOTE! Only used to connect the Crane Interface.

Pin	Name	Function
9	A1	Crawl Right/Hoist
8	B1	Preset Speed 2
7	E1	Limit Switch Right/Hoist
6	V2	Pre-limit Switch Left/Lower
4	E2	Limit switch Left/Lower
3	V1	Pre-limit Switch Right/Hoist
2	A2	Crawl Left/Lower
1	N	Null position
12	B2	Preset Speed 3
14	B3	Preset Speed 4
16	R1	2nd Ramp via Parameter Set B
18	R2	Inverter activated (Low=Inverter deactivated)
13	Gnd	Signal ground
15	Gnd	Signal ground
5	Gnd	Signal ground
10		Unused
11		Unused
17		Unused
19	CR2'	High (24V/8k2 open) when CRIO Relay CR2 activated
20	CR1'	High (24V/8k2 open) when CRIO Relay CR1 activated

2.3.5 X7: Encoder

The encoder signal inputs accept HTL (8 – 30VDC) or TTL (5VDC) level signals.

Specification: See § 5.10, page 19.

Pin	Name	Function
1	Gnd	Signal ground
2	A	Sensor A
3	A'	Sensor A'
4	22V	Supply voltage to sensor. Open voltage 22V, serial impedance 41.4Ω. 200mA max
5	B	Sensor B
6	B'	Sensor B'

3. CRANE INTERFACE

3.1 Crane Interface

The Crane Interface is a separate option and is connected to the CRIO Card.

Advantages:

- Mains isolation, better EMC
- Easy commissioning
- Easy faultfinding for service

There are two versions:

- 24VDC input signals
- 230VAC input signals.

For other voltages contact your supplier.

NOTE! When the Crane Interface is used, the CRIO Connectors X1 and X5 are not used.

3.2 Mounting the Crane Interface

The Crane Interface is supplied in a bracket for mounting on a DIN-rail outside the inverter. When the CRIO Card is mounted in the inverter (possible for VFX) the Sub-d connectors are at the bottom of the inverter, see Fig. 4, page 9. When the CRIO Card is also mounted outside the inverter (necessary for VFB) the Crane Interface is connected directly to the CRIO Card, see Fig. 5, page 9.




Fig. 4: Mounting the Crane Interface when the CRIO is mounted inside the inverter (possible for VFX).




Fig. 5: Mounting the Crane Interface when the CRIO is mounted outside the inverter (necessary for VFB).

3.3 Crane Interface layout

The layout is shown in Fig. 6, page 10. The LED's indicate the status of the inputs and relays. F1 is the

mains supply fuse and F2 the transformer secondary fuse.




Fig. 6: Crane Interface layout.

3.4 Crane Interface connections

All control inputs 1-12 are active high.

24VDC version:

Input voltage 15-36V typ
Input resistance 2.7kΩ
Input current 7mA typ @ 24VDC

230VAC version:

Input voltage 120-250VAC typ
Input resistance 27kΩ
Input current 5mA typ @ 230VAC

NOTE! The inputs E1, E2, V1, V2, R2 and NULL must connected to +24VDC (or 230V for Crane Interface) when not used.

Nr	Name	Function
1	A1	Crawl Speed H/R
2	B1	Preset Speed 2
3	E1	Limit Switch H/R
4	V2	Prelimit Switch L/L
5	E2	Limit Switch L/L
6	V1	Prelimit Switch H/R
7	A2	Crawl Speed L/L
8	Null	Null position
9	B2	Preset Speed 3
10	B3	Preset Speed 4
11	R1	2 nd Acc/Dec Ramp
12	R2	Cut
13	Gnd	Ground connection for control signals
14	CR1 P	Identical function as CRIO Relay 1. 250VAC 1A max.
15	CR1 NC	
16	CR1 NO	
17	CR2 P	Identical function as CRIO Relay 2. 250VAC 1A max.
18	CR2 NC	
19	CR2 NO	
20	230V~	Mains supply for the Crane Interface. 30mA typ.
21		
22	PE	

4. SETUP CRIO AND VFB/VFX

NOTE! All window numbers refer to the set-up menu as described in the VFB/VFX manual.

4.1 Connecting CRIO and Crane Interface

4.1.1 CRIO inside VFX

See Fig. 1, page 6; Fig. 2, page 6 and § 2.2.1, page 6. Generally the manufacturer does this.

4.1.2 CRIO outside VFB

See Fig. 1, page 6; Fig. 3, page 7 and § 2.2.2, page 6. The CRIO is to be mounted on a DIN-rail. Connect the cable between Control Board X5 and CRIO X3 and tighten the gland.

4.1.3 Crane Interface (with CRIO inside VFX)

See Fig. 4, page 9 and Fig. 6, page 10. Connect the cables as indicated.

4.1.4 Crane Interface (with CRIO outside VFB)

See Fig. 5, page 9 and Fig. 6, page 10. The CRIO can be mounted on a DIN-rail. Connect the cable between Control Board X5 and CRIO X3 and tighten the gland. Connect the cable between CRIO X6 and Crane Interface CX1, CX2 as indicated.

4.2 External circuitry

NOTE! The inputs **E1, E2, V1, V2, R2** and **NULL** must connected to **+24VDC** (or **230V** for Crane Interface) when not used.

4.2.1 With 4-Speed control

See wiring example in § 7, page 23. For control selection, see § 5.1, page 14 and § 6.1.2, page 20.

4.2.2 With 3-Position control

See wiring example in § 8, page 25. For control selection, see § 5.1, page 14 and § 6.1.2, page 20.

4.2.3 With analogue control

See wiring example in § 9, page 27. For control selection, see § 5.1, page 14 and § 6.1.2, page 20.

4.2.4 PTC and Encoder

Connect the PTC to CRIO X2, see § 2.3.2, page 7 or **leave the bridge wire if no PTC is used.**

Connect the Encoder to CRIO X7; see § 2.3.5, page 8.

4.2.5 Brake

Fig. 14, page 16 shows the recommended connection for Deviation (CRIO- Relay 1) and the brake relay. When the deviation function is activated, the brake is activated and the inverter stops. When the joystick is put in the null position within 3s, a restart can be made, otherwise the inverter trips with the trip message "Deviation".

4.2.6 Functionality of VFB/VFX User Interface when CRIO Card connected

When the CRIO Card is connected, some of the terminals of the VFB/VFX User Interface X1 have a different function, which are stated in the table below (Refer also to the VFB/VFX manual):

X1 Nr	Name	Function
1	+10VDC	
2	AnIn1+	4-Speed controller: Scaling.
3	AnIn1-	Analogue Control: Reference.
4	AnIn2+	
5	AnIn2-	
6	-10VDC	
7	Common	
8	RunL	Both HIGH: Motor kept magnetized in Stop Mode.
9	RunR	
10	Enable	Must be made HIGH.
11	+24VDC	
12	Common	
13	AnOut1	
14	AnOut2	
15	Common	
16	DigIn1	
17	DigIn2	
18	DigIn3	
19	DigIn4	
20	DigOut1	
21	DigOut2	
22	Reset	

4.3 Programming the VFB/VFX

The starting point is the default setting for all functions and parameters.

4.3.1 Unhidden windows when CRIO Card connected and their defaults

When the CRIO Card is connected, a number of windows will be unhidden in the menu upon detection of the CRIO Card by the VFB/VFX.

Program acc. to the required functionality for the application. Refer to § 6.1, page 20.

The unhidden windows are (See § 6, page 20 for the functional description of these windows):

Window	Function	Default
251	Encoder On/Off	Off (set by user)
252	Number of Encoder pulses	1024
271	PTC On/Off	Off (set by user)
281	CRIO On/Off	Off (set by user)
282	CRIO Control selection	4-Speed
283	CRIO Relay 2 function	Brake
284	Deviation Time	100ms
285	Set Load	100%

4.3.2 Changed defaults when CRIO Card activated

Activate the CRIO Card by setting window 281 CRIO On/Off = On.

After executing Load Defaults in window 235 a number of defaults will change, compared to the standard default settings.

The changed VFB/VFX defaults are:

Window	Function	Changed default
212	Reference Control	Option
213	Run/Stop Control	Option

See § 5.3, page 15.

317	tbh	0.5s
318	tbf	0.5s
319	tba	0.5s
32I	Start Speed	10rpm

See § 5.1, page 14 for the different speed settings, depending on the type of control.

326	Preset Speed 1: Prelimit switch speed	150rpm
327	Preset Speed 2	600rpm
328	Preset Speed 3	1000rpm
329	Preset Speed 4	1500rpm
32A	Preset Speed 5: Crawl speed H/R	150rpm
32B	Preset Speed 6: Crawl speed L/L	150rpm

See § 5.2, page 14.

32C	Preset Speed 7: Deviation bandwidth	100rpm
-----	-------------------------------------	---------------

See § 5.9, page 18.

322	Max Speed	1500rpm
-----	-----------	----------------

See § 4.3.6, page 13.

353	Motor lost	Trip
-----	------------	-------------

4.3.3 Programming general

Since the VFB/VFX starts in Parameter Set B because of the 2nd Acc Time, it is best to program Parameter Set B first and then copy B into A (window 233). Subsequently the Acc Time and Dec

Time in Parameter Set B can be set to their required values (window 311 and 313).

4.3.4 Disconnecting the CRIO Card



WARNING! Before disconnecting the CRIO Card, it must be deactivated in window 281 CRIO = Off.

4.3.5 Programming VFB/VFX for riding applications

NOTE! If more than one motor is connected to the VFB/VFX for riding applications, set 211 Drive Mode = V/Hz. Contact your supplier.

- For riding applications the deviation function is not necessary. Set Jumper J101 acc. to § 2.1.1, page 6 “Deviation off”.
- Set in window 281 CRIO = On and execute Load Defaults in window 235.
- Enter the motor data acc. to menu 220 and execute a short ID-run without rotating the motor (window 228) for optimum performance.



WARNING! It is dangerous to perform an extended ID-run with the motor coupled to the cable drum, because then the motor will run at high speeds in both directions

- After initialising the inverter operates in Parameter Set B, because it always starts at 0rpm with the 2nd Acc/Dec Time.
- Set the control selection in window 282 acc. to the used controller, see § 5.1, page 14.
- Set all parameters in menu 300 and all I/O in menu 400 as required by the application.
- Set all the other parameters/functions to their required settings. The Set-up menu List in § 10, page 29 can be used as a guideline and filled in by the user for later reference.
- Copy in window 233 Parameter Set B to A (B>A).
- Change window 311 B:Acc Time and 313 B:Dec Time to the required values.

NOTE! When different maximum speeds are programmed, the largest one should be programmed in Parameter Set A. It is however recommended to keep all parameters in Parameter Set A and B equal and, if necessary, to only make the acceleration time [311] and deceleration time [313] different.

4.3.6 Programming VFB/VFX for hoisting applications



WARNING! Contact your supplier in case of multi-motor operation in hoisting applications.

- When for hoisting applications the deviation function is needed (strongly recommended), it is activated by setting Jumper J101 acc. to § 2.1.1, page 6 “Deviation on”.
- Set in window 281 CRIO = On and execute Load Defaults in window 235.
- Enter the motor data acc. to menu 220 and execute a short ID-run without rotating the motor (window 228) for optimum performance.



WARNING! It is dangerous to perform an extended ID-run with the motor coupled to the cable drum, because then the motor will run at high speeds in both directions

- Set the control selection in window 282 acc. to the used controller, see § 5.1, page 14.
- Set all parameters in menu 300 and all I/O in menu 400 as required by the application.
- Set all the other parameters/functions to their required settings. The Set-up menu List in § 10, page 29 can be used as a guideline and filled in by the user for later reference.
- Copy in window 233 Parameter Set B to A (B>A).
- Change window 311 B:Acc Time and 313 B:Dec Time to the required values.

NOTE! When different maximum speeds are programmed, the largest one should be programmed in Parameter Set A. It is however recommended to keep all parameters in Parameter Set A and B equal and, if necessary, to only make the acceleration time [311] and deceleration time [313] different.



WARNING! Make sure the encoder function (window 251) and the deviation function (Jumper j 101) are activated. The function „motor lost“ (window 353) must be set to „trip“. Check these functions carefully. They are safety related and prevent the load from falling down.

5. FUNCTIONS

5.1 Control

The crane is operated by a controller. There are three possible configurations, which are selected in window 282.

5.1.1 4-Speed controller

With the 4-Speed controller, as the name suggests, one of four speeds can be selected by moving the controller to the position, corresponding to the desired speed. There are four speeds in both directions, which can be adjusted in the menu.




Fig. 7: 4-Speed controller.

5.1.2 3-Position switch

With the 3-Position switch the Crawl speed is selected in the first position and in the extreme position the speed is increased, depending on the direction, up to Preset Speed 4.




Fig. 8: 3-Position switch.

5.1.3 Analogue control

With an Analogue control the speed is determined by an analogue signal from the controller, which is similar to a potentiometer. Since the CRIO Card has no analogue input, these kinds of controllers

must be connected to AnIn1 on the VFB/VFX User Interface. See the VFB/VFX Manual.




Fig. 9: Analogue control.

5.2 Deviation

Deviation is a special safeguard function for a crane's hoisting function. For safety reasons it cannot be performed by the inverter itself but must be performed by an independent unit, in this case the CRIO Card, because it functions independently after it has been initialised, although it uses info from the inverter.



WARNING! Depending on local regulations it may be necessary to install a fully independent safety system, including control of the mechanical brake.

5.2.1 Deviation function

The deviation function compares the actual reference speed on the inverter's internal ramp signal with the motor speed from the encoder and determines whether they match or not, whereby the direction is also taken into account. If they do not match, the load is assumed to be "lost", the CRIO switches Relay CR1 (Deviation) and the inverter activates the relay output for mechanical brake and trips. Also the communication between CRIO and inverter is monitored. After a communication time-out of ca. 600ms the CRIO relays activate accordingly. This condition is automatically ended when the communication is restored.



CAUTION! When 282 Control = Analogue the inverter reference speed does not come from the CRIO Card but from an analogue input AnIn1 or AnIn2.

The bandwidth within which the difference between reference and encoder speed must lie, is set by Preset Speed 7 in window 32C. If it is exceeded, the deviation function becomes active.

The minimum duration for the difference to exceed the bandwidth before the deviation function is activated, is set in window 284 "Dev. Time".

NOTE! For the Deviation function an Encoder is mandatory.

5.2.2 (De)activating deviation function

For riding movements the deviation function is switched off by the jumper on the CRIO Card, see § 2.1.1, page 6 (PCB held in position as drawn in § 2.1, page 6)

Jumper J101 setting	
<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; width: 20px; height: 20px; position: relative; margin-right: 5px;"> <div style="background-color: black; width: 10px; height: 10px; position: absolute; top: 0; left: 0;"></div> </div> <div style="display: flex; flex-direction: column; justify-content: space-around; width: 20px;"> 321 </div> </div>	Deviation function deactivated.
<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; width: 20px; height: 20px; position: relative; margin-right: 5px;"> <div style="background-color: black; width: 10px; height: 10px; position: absolute; top: 0; left: 0;"></div> </div> <div style="display: flex; flex-direction: column; justify-content: space-around; width: 20px;"> 321 </div> </div>	Deviation function activated.

5.3 Mechanical brake

The mechanical brake can be controlled by selecting the function of one of the relays R1 and R2 on the Control Board or one of the relays CR1 and CR2 to "Brake". This is the default setting of relay CR2.

5.3.1 Mechanical brake function at start

See Fig. 10, page 15. After a start hoisting command the speed increases up to the Start Speed H/R. After **tbh** the speed is allowed to increase further, depending on the speed reference of course. The brake should be released within **tbh**, or **tbh** must be set to a value longer the brake release time. Only then it is ensured that the load will be held when the brake is released.




Fig. 10: Diagram for brake function at start of hoisting.

See Fig. 11, page 15. After a start lowering command the speed increases up to the Start Speed to build up torque to hold the load. After **tbh** the speed is allowed to decrease and increase in the opposite direction, depending on the speed reference of course. The brake should be released within **tbh**, or **tbh** must be set to a value longer the brake release time. Only then it is ensured that the load will be held when the brake is released.




Fig. 11: Diagram for brake function at start of lowering.

5.3.2 Mechanical brake function at stop

See Fig. 12, page 16. When a stop command is issued during hoisting the hoisting speed is decreased down to 0rpm. During **tba** the load is held and it is possible to increase the hoisting speed again. During **tbf** the brake is engaged and **tbf** must be set longer than the brake engage time to ensure the brake is on when the torque is finally reduced to zero.




Fig. 12: Diagram for brake function at stop hoisting.

See Fig. 13, page 16. When a stop command is issued during lowering the speed is decreased to 0rpm. During **tba** the load is held and it is possible to lower or hoist again. During **tbf** the brake is engaged and **tbf** must be set longer than the brake engage time to ensure the brake is on when the torque is finally reduced to zero.




Fig. 13: Diagram for brake function at stop lowering.

5.3.3 Cooperation of brake and deviation function

To get the fastest response to a deviation condition, it is recommended to put the CRIO Relay 1 N/O contact (No Trip/Deviation) **in series** with the N/O contacts of the brake relay (either CRIO Relay 2 or one of the relays on the control board, depending on programming). This series connection should be put in the brake circuit.




Fig. 14: Recommended brake circuitry.

Fig. 14, page 16 shows the recommended connection for Deviation (CRIO- Relay 1) and the brake relay. When the deviation function is activated, the brake is activated and the inverter stops. When the joystick is put in the null position within 3s, a restart can be made, otherwise the inverter trips with the trip message "Deviation".

When after activation of the deviation function a restart shall generally be prevented, CRIO Relay 1 shall operate the mains contactor.

5.3.4 Recommendation for tbh

It is recommended to set [317] Brake Release Time tbh to a value of 0.3s more than the actual used release time of the mechanical brake to compensate for the communication delay between CRIO and VFB/VFX.

5.4 Magnetizing the motor

In order to get the fastest motor response to a Run command (derived from the controller action), the motor maybe kept magnetized during stop. When in Window 315 Start Mode=Normal DC is selected, the motor is first magnetized every time before a run command is executed. In many crane applications this takes too long. It is therefore possible to keep the motor magnetized by making the Run R and Run L inputs on the VFB/VFX User Interface (X1 #8 and #9) High. When the motor is stopped, it will be kept magnetized. The current level is ca. $0.4 I_{NOM}$. In that case heat is dissipated in the rotor and the motor must be dimensioned for this use. Forced external cooling is recommended.



WARNING! When the motor is permanently magnetized, it shall be dimensioned correspondingly. Forced external cooling is recommended.

5.5 (Pre)limit switches

The (pre)limit switches are connected to the inputs E1, E2, V1, V2, see Fig. 22, page 23, Fig. 24, page 25 and Fig. 26, page 27, and should open when active. The following diagram illustrates their effect:




Fig. 15: Effect of (pre)limit switches.

In between the two Prelimit switches the inverter operates normally.

When only a Prelimit switch is active the inverter is allowed to move with the prevailing Crawl Speed or Preset Speed 1 (or a speed in between these values in case of 3-Position switch or Analogue control) in the direction of the Limit switch or is allowed to move in the opposite direction at any speed.

When a Limit switch is active the inverter stops (and the brake is activated) and is only allowed to move in the opposite direction at any speed.

NOTE! The inputs E1, E2, V1, V2, R2 and NULL must connected to +24VDC (or 230V for Crane Interface) when not used.

5.5.1 Operation of limit switch without activated prelimit switch

Sometimes the limit switch can be activated without an activated prelimit switch, e.g. when two traverses ride over the same rail with a limit switch on each cable reel or as an anti-collision mechanism.

Upon activation the traverse is stopped. Contrary to normal limit switch operation, the traverse can be moved again in both directions after the controller has been in the null-position, provided the limit switch concerned is deactivated.

5.6 Fast reverse

When during hoisting the controller is moved in the opposite speed direction, the inverter reverses fast and decelerates with the 2nd Dec Time.

It keeps decelerating with the 2nd Dec Time until 0rpm, after which it accelerates in the opposite speed direction with the 2nd Acc Time to Crawl Speed. Then, depending on the controller position, it accelerates further to the desired speed. See diagrams in § 7, page 23, § 8, page 25 and § 9, page 27.

NOTE! The 2nd Dec Time and 2nd Acc Time are set in Parameter Set B.

5.7 Scaling

NOTE! Only applicable when controlled by a 4-Speed controller.

When window 282 Control = 4-Speed, the inverter speed is scaled by AnIn1. If scaling is not required, AnIn1 must be connected to +10V (or +20mA).

The scaling works acc. to the diagram in Fig. 16, page 18:




Fig. 16: Effect of scaling the speed reference from the CRIO Card.

NOTE! If no scaling is used when 4-Speed control is selected, AnIn 1 has to be connected to +10V by a jumper, see Fig. 22.

5.8 CRIO Relay CR1

This relay has a fixed function “No Trip”.




Fig. 17: CRIO Relay CR1 function.

NOTE! When the inverter is switched off, CRIO Relay CR1 is open and indicates a “Trip” condition where there is none. This must be dealt with by the user to prevent a false trip warning.

5.9 Load dependent field weakening operation

Load dependent field weakening operation allows hoisting/lowering at speeds above sync speed when the load is low or zero (empty hook).




Fig. 18: Theoretical load dependent field weakening operation.

The maximum over synchronous speed can be set between Sync. Speed and $2 \times \text{Sync. Speed}$ via Preset Speed 4 in window 329. If Preset Speed 4 is set to a value $< \text{Sync Speed}$, load dependent field weakening operation is not active.

Set [322] Max Speed at least 200rpm higher than Preset Speed 4, to give the internal speed PI controller room for regulation. The load above which the load dependent field weakening operation is active can be set in window 285, see § 6.1.5, page 20. Read in window 100 or 620 the torque indication in % with the max. load used in practice at sync speed and set this value in window 285 accordingly. For more information about field weakening operation, contact your sales representative.




Fig. 19: Settings for load dependent field weakening operation.

5.10 Encoder

The encoder is to be connected to connector X7 and is used to measure the real motor shaft speed. When the deviation function, see § 5.2, page 14, is used, an encoder is mandatory.

The encoder function can be (de)activated, see § 6.3.1, page 21.

The number of impulses per encoder revolution can be adjusted acc. to 6.3.2 between 5 and 5500 with a default of 1024. Select the encoder number of impulses acc. to the max. encoder input frequency at max. speed.

The encoder signal inputs accept HTL (8–30VDC) or TTL (5VDC) level signals.

Sw. Level A-A'/B-B' (differential)	±0.5V to ±1V max (see Fig. 20, page 19).
Input current A, B	±9.8mA max
Input current A', B'	±4.2mA max
Supply to encoder	22VDC open, 200mA max Serial impedance 41.4Ω
Max input frequency	50kHz
Pulse range (adjustable in inverter)	5 – 5500 pulse/rev




Fig. 20: Encoder inputs A-A'/B-B' switching level



WARNING! Make sure the encoder frequency does not exceed the max. input frequency at max. speed.

5.11 PTC

The PTC function consists of a galvanically isolated PTC circuit for connecting motor thermistors acc. to DIN44081/44082 with the following spec:

Number of PTC's	1, 3 or 6 acc. to DIN44081/44082
Switching point	2V ±10% (Pin 1 "+", pin 2 "-")
Switch-off (trip) at	2825Ω ±10%
Switch-on at	1500Ω ±10%

The PTC function can be (de)activated, see § 6.2.1, page 21.

6. VFB/VFX MENU

In the VFB/VFX a number of windows appear in the menu when the CRIO Card is connected and automatically recognised.

In certain windows a different selection, compared with the standard settings, has to be made.

6.1 Additional functions for CRIO in Window 280

6.1.1 281 CRIO Card

When the CRIO Card is connected, it is possible to (de)activate the CRIO Card.

<div>281 CRIO Card</div> <div>Stp On</div>	
Default:	Off
Selection:	Off, On
Off	CRIO Card deactivated
On	CRIO Card activated

6.1.2 282 Control

To select the type of control . See § 5.1, page 14.

<div>282 Control</div> <div>Stp 4-Speed</div>	
Default:	4-Speed
Selection:	3-Pos, 4-Speed, Analogue
3-Pos	3-Position switch
4-Speed	4-Speed controller
Analogue	Analogue control

6.1.3 283 CRIO Relay CR2

To select the function of CRIO Relay CR2 on the CRIO Card. See § 2.3.1, page 7.

<div>283 CRIO Relay 2</div> <div>Stp Brake</div>	
Default:	Brake
Selection:	Run, Stop, Acc/Dec, At speed, At max speed, No trip, Trip, Autoreset Trip, Limit, Warning, Ready, $T=T_{LIM}$, $I>I_{NOM}$, Brake, Sgnl<Offset, Alarm, Pre-alarm, Max Alarm, Max Pre-alarm, Min Pre-alarm, Deviation
Run	The inverter output is active.
Stop	The inverter output is not active.
Acc/Dec	The speed is increasing or decreasing.
At speed	The Output Speed =Reference Speed.

At max speed	The speed is limited by the Maximum Speed.
No trip	No trip condition active.
Trip	A Trip condition is active.
Limit	A Limit condition is active.
Warning	A warning condition is active.
Ready	The inverter is ready for operation. This means that the inverter is powered up and healthy and ready to take a command.
$T=T_{LIM}$	The Torque is limited by the Torque Limit function.
$I>I_{NOM}$	The output current is higher than the inverter rated current.
Brake	The output is used to control a mechanical brake.
Sgnl<Offset	One of the AnIn input signals is lower than 75% of the offset level.
Alarm	Max or Min Alarm level reached.
Pre-alarm	Max or Min Pre-alarm level reached.
Max Alarm	Max Alarm level reached.
Max Pre-alarm	Max Pre-alarm level reached.
Min Alarm	Min Alarm level reached.
Min Pre-Alarm	Min Pre-alarm level reached.
Deviation	Tripped on deviation.

6.1.4 284 Deviation Time

To set the time during which the deviation condition must be active, before the inverter trips. See also § 5.2, page 14.

<div>284 Dev. Time</div> <div>Stp A: ms</div>	
Default:	100ms
Range:	50 – 1000ms

6.1.5 285 Set Load

To set the load above which the VFB/VFX goes into load dependent field weakening operation. See also § 5.9, page 18.

<div>285 Set Load</div> <div>Stp A: %</div>	
Default:	100%
Range:	25 – 100%, OFF

When set to OFF, the load dependent field weakening function is switched off.

6.2 Added PTC function for CRIO in Window 270

6.2.1 271 PTC (Card)

When the CRIO Card is connected, it is possible to (de)activate the PTC function.

<div>271 PTC Card Stp On</div>	
Default:	Off
Selection:	Off, On
Off	PTC function on CRIO Card deactivated
On	PTC function on CRIO Card activated

6.3 Added Encoder functions for CRIO in Window 250

6.3.1 251 Encoder (Card)

When the CRIO Card is connected, it is possible to (de)activate the encoder function.

<div>251 Encoder Card Stp On</div>	
Default:	Off
Selection:	Off, On
Off	Encoder function on CRIO Card deactivated
On	Encoder function on CRIO Card activated

6.3.2 252 Encoder pulses

To adjust the number of pulses per revolution for the connected encoder, see § 5.9, page 18.

<div>252 Encoder Puls Stp 1024</div>	
Default:	1024
Range:	5 - 5500

7. 4-SPEED CONTROLLER OPERATION




Fig. 21: General diagram for 4-Speed controller operation.

7.1 Windows for setting the speeds for 4-Speed controller operation

Window	Function
282	4-Speed
326	Prelimit switch speed
327	Preset Speed 2
328	Preset Speed 3
329	Preset Speed 4
32A	Crawl Speed H/R
32B	Crawl Speed L/L
32I	Start Speed

7.2 Windows for setting the brake functions

Window	Function/Selection
317	tbh Brake Release time
318	tbf Brake Engage time
319	tba Brake Wait time

NOTE! The inputs E1, E2, V1, V2, R2 and NULL must connected to +24VDC (or 230V for Crane Interface) when not used.

7.3 Connection example for 4-Speed controller operation




Fig. 22: Connection diagram for 4-Speed controller operation

8. 3-POS SWITCH OPERATION




Fig. 23: General diagram for 3-position switch operation.

8.1 Windows for setting the speeds for 3-Position switch operation

Window	Function/Selection
282	3-Position

326	Prelimit switch speed
329	Preset Speed 4
32A	Crawl Speed H/R
32B	Crawl Speed L/L
32I	Start Speed

8.2 Windows for setting the brake functions

Window	Function/Selection
317	tbh Brake Release time
318	tbf Brake Engage time
319	tba Brake Wait time

NOTE! The inputs E1, E2, V1, V2, R2 and NULL must be connected to +24VDC (or 230V for Crane Interface) when not used.

8.3 Connection example for 3-Position switch operation




Fig. 24: Connection diagram for 3-Position switch operation

9. ANALOGUE CONTROL




Fig. 25: General diagram for analogue control operation.

9.1 Windows for setting up analogue control operation

Window	Function/Selection
282	Analogue

326	Prelimit switch speed
329	Preset Speed 4
32A	Crawl Speed H/R
32B	Crawl Speed L/L
32I	Start Speed

9.2 Windows for setting the brake functions

Window	Function/Selection
317	t _{bh} Brake Release time
318	t _{bf} Brake Engage time
319	t _{ba} Brake Wait time

9.3 Window for AnIn1 Setup

Window	Function/Selection
412	2-10V/4-20mA (if 4-20mA to be selected)

NOTE! The inputs E1, E2, V1, V2, R2 and NULL must connected to +24VDC (or 230V for Crane Interface) when not used.

9.4 Connection example for 4-20mA analogue control operation




Fig. 26: Connection diagram for 4-20mA analogue control operation

10. SETUP MENU LIST

VFB/VFX type	
Serial number	
Software version VFB/VFX	
Software version CRIO	
Brake resistor P [kW]	
R [Ω]	
δ [%]	
Motor type	
Encoder type	

Name
Date
Company
Project
Drive

Bold = Changed default for CRIO

Deviation function activated by **J101**. (For hoisting applications strongly recommended).

Select window 211 Drive Mode = V/Hz Mode for multi-motor operation (for riding applications). For hoisting applications multi-motor operation is not recommended.

		Default	Custom	
100	START-UP WINDOW			
	110 * 1 st Line	Speed		
	120 * 2 nd Line	Torque		
200	MAIN SETUP			
	210	Operation		
	211	Drive Mode	Speed	Set to V/Hz for multi-motor operation (riding only!)
	212	Ref Control	Option	Automatically when CRIO=On [281]
	213	Run/Stop Ctrl	Option	Automatically when CRIO=On [281]
	214	Rotation	R+L	
	215	Level/Edge	Level	
	220	Motor Data		
	221	Motor Power	P _{NOM}	
	222	Motor Voltage	U _{NOM}	
	223	Motor Frequency	50	
	224	Motor Current	I _{NOM}	
	225	Motor Speed	n _{MOT}	
	226	Motor Cosphi	(P _{NOM})	Depends on P _{NOM} .
	227	Motor Ventilation	Self	
	228	Motor ID-run	Off	Use short ID-run only!
	230	Utility		
	231	* Language	English	
	232	* Lock Code?	0291	Locking after Set up recommended.
	233	* Copy Set	A>B	After setting up Copy B>A.
	234	* Select Set	A	
	235	Load Default	A	
	236	* Copy to CP	CP M 1	
	237	CP>All Sets	CP M 1	
	238	CP>Active Set	CP M 1	
	239	CP>Settings	CP M 1	
	240	Auto restart		
	241	Number of trips	0	
	242	Overtemperature	No	
	243	Overcurrent	No	
	244	Overvoltage D	No	
	245	Overvoltage G	No	
	246	Overvoltage L	No	
	247	Motortemp	No	
	248	External trip	No	
	249	Motor lost	No	

		Default	Custom		
	24A	Alarm	No		
	24B	Locked rotor	No		
	24C	Power fault	No		
250	Option: Encoder			Commission first without encoder, Then activate encoder (when connected), when inverter in torque limit. Test the signals.	
	251	Encoder	Off		
	252	Encoder pulses	1024		
260	Option: Serial Communication				
	261	Baud rate	9600		
	262	Address	1		
270	Option: PTC card				
	271	PTC Card	Off	On when PTC connected to CRIO X2.	
280	Option: CRIO Card				
	281	CRIO Card	Off		
	282	CRIO Control	4speed	Control selection.	
	283	CRIO Relay 2	Brake	For control of mechanical brake.	
	284	Dev. Time	200	Deviation time	
	285	Set Load	100	Above this load the field weakening operation is active	
300	PARAMETER SETS				
310	* Run/Stop		A	B	
	311	* Acc Time	2		Increase to suit application.
	312	* Acc Ramp	Lin		S-Curve may be advantageous.
	313	* Dec Time	2		Increase to suit application.
	314	* Dec Ramp	Lin		S-Curve may be advantageous.
	315	* Start Mode	Normal		
	316	* Stop Mode	Decel		
	317	* tbh Brake rel.	0.5		Time to release mechanical brake.
	318	* tbf Brake eng.	0.5		Time to engage mechanical brake.
	319	* tba Wait brake	0.5		Time to hold the load before mechanical brake engages.
	31A	* Vector brake	Off		
	31B	* Q-Stop time	0.0		
	31C	* Spin start	Off		
320	* Speeds				
	321	* Min Speed	0		Must remain set to 0rpm!
	322	* Max Speed	Sync		
	323	* Min Spd Mode	Scale		
	324	* Speed Direction	R+L		
	325	* MotPot function	Nonvola		
	326	* Preset Speed 1	100		Prelimit switch speed
	327	* Preset Speed 2	600		Preset Speed 2
	328	* Preset Speed 3	1000		Preset Speed 3
	329	* Preset Speed 4	1500		Preset Speed 4
	32A	* Preset Speed 5	150		Crawl speed H/R
	32B	* Preset Speed 6	150		Crawl Speed L/L
	32C	* Preset Speed 7	100		Deviation bandwidth
	32D	* Skip Spd 1 LO	0		
	32E	* Skip Spd 1 HI	0		
	32F	* Skip Spd 2 LO	0		
	32G	* Skip Spd 2 HI	0		
	32H	* Jog Speed	50		
	32I	* Start Speed	10		Speed during tbh Brake Release Time
330	* Torques				
	331	* Max Torque	150		
340	* Controllers				
	341	* Spd PI Auto	Off		
	342	* Speed P Gain	5.0		To suit application.

		Default	Custom	
343	* Speed I Time	0.1		To suit application.
344	* Flux Optimise	Off		
345	* PID Controller	Off		
346	* PID P Gain	1.0		
347	* PID I Time	1.00		
348	* PID D Time	0.00		
350	* Limits/Protections			
351	* Low Volt OR	Off		On when Mains Dips expected.
352	* Rotor locked	Off		
353	* Motor lost	Trip		Safety item for hoisting drives
354	* Motor I ² t Type	Trip		
355	* Motor I ² t I	I _{NOM}		
356	* OverV Ctrl	On		Set to Off when braking by brake resistor only
400	I/O			
410	Analogue Inputs			
411	AnIn1 Function	Speed		Used for Analogue Control or scaling.
412	AnIn1 Set up	0-10V/ 0-20mA		
413	AnIn1 Offset	0		
414	AnIn1 Gain	1.00		
415	AnIn1 Bipolar	Off		
416	AnIn2 Function	Off		
417	AnIn2 Set up	0-10V/ 0-20mA		
418	AnIn2 Offset	0		
419	AnIn2 Gain	1.00		
41A	AnIn2 Bipolar	Off		
420	Digital Inputs			
421	DigIn 1	Off		
422	DigIn 2	Off		
423	DigIn 3	Off		
424	DigIn 4	Off		
430	Analogue Outputs			
431	* AnOut 1 Funct	Speed		
432	* AnOut 1 Set up	0-10V/ 0-20mA		
433	* AnOut 1 Offset	0		
434	* AnOut 1 Gain	1.00		
435	* AnOut 1 Bipolar	Off		
436	* AnOut 2 Funct	Torque		
437	* AnOut 2 Set-up	0-10V/ 0-20mA		
438	* AnOut 2 Offset	0		
439	* AnOut 2 Gain	1.00		
43A	* AnOut 2 Bipolar	Off		
440	Digital Outputs			
441	* DigOut 1 Funct	Run		
442	* DigOut 2 Funct	Brake		
450	Relays			
451	* Relay 1 Funct	Ready		
452	* Relay 2 Funct	Trip		
500	SET/VIEW REFERENCE VALUE			
600	VIEW OPERATION			
610	Speed			
620	Torque			
630	Shaft power			
640	Electrical power			

		Default	Custom	
650	Current			Displays the inverter status.
660	Voltage			
670	Frequency			
680	DC-Link Voltage			
690	Heat sink temperature			
6A0	FI Status			
6B0	Digital input status			
6C0	Analogue input status			
6D0	Run Time			
	6D1 * Reset RUN Tm	No		
6E0	Mains Time			Displays status of Digital Inputs on Control Board.
6F0	Energy			
	6F1 * Reset Energy	No		
6G0	Process Speed			
	6G1 * Set Prc Unit	None		
	6G2 * Set Prc Scale	1.000		
6H0	Warnings			
700	VIEW TRIP LOG	Cause	Time	Displays the actual warning.
710	Trip 1			
720	Trip 2			
730	Trip 3			
740	Trip 4			
750	Trip 5			
760	Trip 6			
770	Trip 7			
780	Trip 8			
790	Trip 9			
7A0	Trip 10			
7B0	Reset Trip Log	No		
800	MONITOR			
810	Alarm Functions			
	811 * Alarm select	Off		
	812 * Ramp enable	Off		
	813 * Start delay	2		
	814 * Alarm delay	0.1		
	815 * Auto Set	No		
	816 * Max Alarm	150		
	817 * Max Pre-alarm	110		
	818 * Min Alarm	0		
	819 * Min Pre-alarm	90		
820	Comparators			
	821 * CA1 Value	Speed		
	822 * CA1 Constant	300rpm		
	823 * CA2 Value	Torque		
	824 * CA2 Constant	10%		
	825 * CD1	Run		
	826 * CD2	DigIn1		
830	Logic Y			
	831 * Y Comp 1	CA1		
	832 * Y Operator 1	&		
	833 * Y Comp 2	!A2		
	834 * Y Operator 2	&		
	835 * Y Comp 3	CD1		
840	Logic Z			
	841 * Z Comp 1	CA1		
	842 * Z Operator 1	&		

		Default	Custom
843	* Z Comp 2	!A2	
844	* Z Operator 2	&	
845	* Z Comp 3	CD1	
900	VIEW SYSTEM DATA		
910	Inverter Type		
920	Software		

NOTE! At starting the inverter with CR10 operates in Parameter Set B, because the 2nd Ramps are active. After setting up, Parameter Set B is to be copied in Parameter Set A, see window 233 and, if necessary, the different settings for Parameter Set B can be programmed.

NOTE! When different maximum speeds are programmed, the largest one should be programmed in Parameter Set A. It is however recommended to keep all parameters in Parameter Set A and B equal and, if necessary, to only make the acceleration time [311] and deceleration time [313] different.

11. INDEX

2

- 2nd Acc Time 12, 17
- 2nd Acc/Dec Time 13
- 2nd Dec Time 17

3

- 3-Position switch 14, 20
- 3-Position switch operation 25
 - connections 25
 - windows for brake 25
 - windows for speeds 25

4

- 4-Speed controller... 14, 17, 20
- 4-Speed controller operation 23
 - connections 23
 - scaling 17
 - windows for brake 23
 - windows for speeds 23

A

- analogue control..... 14, 20, 27
 - connections 27
 - window for Set-up 27
 - windows for brake 27
 - windows for speeds 27
- analogue input 14
- anti-collision mechanism 17

B

- bandwidth (deviation) 15
- brake..... 11, 14, 15, 16, 17, 20, 23, 25, 27

C

- cautions 5
- collision 17
- communication 14
- connections Crane Interface 10
- connections CRIO 7
- contents Crane Interface..... 5
- contents CRIO option..... 5
- control 14, 20
- controller 14
- cooling motor 17
- Crane Interface 5, 7, 9
 - 230VAC inputs 9
 - 24VDC inputs 9
 - connections 10
 - fuses 10
 - layout 10
 - mounting 9

- other input voltages 9
- CRIO 20
 - activated 20
 - connections 7
 - deactivated 20
 - dimensions 6
 - disconnecting 12
 - inside inverter (VFX)..... 6
 - layout 6
 - mounting 6
 - outside inverter (VFB) 6
 - setup 11
 - User Interface 7
- CRIO Card 5
- CRIO Relay 1' 10
- CRIO Relay 2' 10
- CRIO Relay CR1 7, 14, 18
- CRIO Relay CR2 7, 20

D

- danger signs 5
- deviation 11, 14, 16
 - bandwidth 15
 - communication 14
 - safeguard 14
 - safety 14
 - time 15
- deviation function 14
 - activating 15
 - deactivating 15
- dimensions CRIO 6
- DIN-rail 5, 6, 9, 11
- disconnecting CRIO 12

E

- EMC 5, 9
- encoder 14, 19, 21
 - activating 21
 - connections 8
 - deactivating 21
 - impulses 19
 - switching level 19

F

- fast motor response 17
- fast reverse 17
- field weakening 18, 20
- forced external cooling 17
- function VFB/VFX User Interface 11
- fuses 10

I

- ID-run 2
- introduction 5

J

- jumper J101 6, 15, 29

L

- layout Crane Interface 10
- layout CRIO 6
- limit switch 17
- load dependent field weakening operation.. 18, 20

M

- magnetizing the motor 17
- mechanical brake 14, 15, 20
- Motor ID-run 2
- motor response fast 17
- mounting Crane Interface 9
- mounting CRIO 6
- multi-motor operation... 13, 29

P

- prelimit switch 17
- PTC 7, 11, 19, 21
 - activated 21
 - deactivated 21

R

- relay CR2 20

S

- safeguard (deviation) 14
- safety (deviation) 14
- safety instructions 2
- scaling 17, 18
- Setup 11
- snap-off strips 6
 - attached 6
 - detached 6
- software version 2
- standards 5
- sync speed 18

T

- tba 16, 23, 25, 27
- tbf 16, 23, 25, 27
- tbh 15, 16, 23, 25, 27

U

- User Interface CRIO 7
- User Interface VFB/VFX 11

W

warnings	5	271	12, 21	322	12, 23, 25, 27
windows		281	12, 13, 20	326	12, 23, 25, 27
211	29	282..	12, 13, 14, 17, 20, 23, 25,	327	12, 23
212	12	27		328	12, 23
213	12	283	12, 20	329	12, 18
218	12	284	12, 15, 20	32A	12, 23, 25, 27
228	2, 13	285	12, 20	32B	12, 23, 25, 27
233	12, 13	311	12, 13	32C	12, 15
235	12, 13	313	12, 13	32I	12, 23, 25, 27
251	12, 21	315	17	353	12
252	12, 21	317	12, 23, 25, 27	412	27
		318	23, 25, 27		
		319	12, 23, 25, 27		

REPRESENTATIVES

Emotron AB
Box 222 25
SE-250 24 HELSINGBORG
Sweden
Tel. +46 42 169900
Fax +46 42 169949

Emotron Antriebssysteme GmbH
Goethestrasse 6
D-38855 WERNIGERODE
Germany
Tel. +49 3943 92050
Fax +49 3943 92055

Emotron B.V.
P.O. Box 132
5530 AC BLADEL
The Netherlands
Tel. +31 497 389222
Fax +31 497 386275

Emotron Drives (UK) Ltd
Unit 18 Steel fabs Industrial Est
Victoria Crescent, Burton on Trent
Staffordshire, DE14 2QD
Tel. +44 1283 500 808
Fax +44 1283 500 420

Emotron EI-Fi SA
Aribau 229, Ent 1a
E-08021 BARCELONA
Spain
Tel. +34 93 209 14 99
Fax +34 93 209 12 45

Emotron Inc.
3440 Granite Circle
TOLEDO, OH 43617
USA
Tel. +1 (419) 841-7774
Fax +1 (419) 843-5816

K.K. EI-Fi
2-18-4 Hagoromocho
0900021 Tachakawa
J-TOKYO
Japan
Tel. +81 42 528 8820
Fax +81 42 528 8821

For more information please contact your local sales outlet or Emotron company, or visit our website

www.emotron.com