


Type	No. of contacts	Dimension A	Dimension C
01	2	37	57
02	4	52	72
03	6	67	87
04	8	82	102
05	10	97	117
06	12	112	132
07	14	127	147
08	16	142	162
09	18	157	177
10	20	172	192
11	22	187	207
12	24	202	222
13	26	217	237
14	28	232	252
15	30	247	267
16	32	262	282

Example for type-sign  
Signal-cam controller  
No. of contacts  
Second free shaftend



Special please describe  
Link rod  
Mounting angles